



AS4050

	PARTS
1	PCB ASSY
2	CORD REWINDER BUTTON
3	SEAL RING
4	BUTTON SPRING
5	SWITCH BUTTON
6	REAR COVER
7	DENOISING COTTON FOR BOTTOM
8	SWITCH
9	SWITCH STAND
10	SEAL RING FOR AIRINPUT
11	MOTOR HOUSING
12	SEAL RING FOR MOTOR COVER
13	FRONT DETENT FOR MOTOR
14	MOTOR ASSY
15	BACK DETENT FOR MOTOR
16	UNDER COVER OF MOTOR
17	DENOISING COTTON FOR MOTOR
18	SEAL RING FOR JOINT
19	UNIVERSAL WHEEL ASSEMBLY
20	
21	
22	
23	
24	DUCT TUBE
25	CW ASSY
26	AIR CHANNEL SEAL
27	BASE
28	BACK WHEEL
29	RUBBER FOR BACK WHEEL
30	SUBSTANTIAL BUCKLE
31	HEPA ASSEMBLY FOR WIND OUTPUT
32	WIND OUTPUT BOARD
34-1	DH062 Metal brush
34-2	NOZZLE
34-3	SMALL BRUSH
34-4	TELESCOPIC METALTUBE
34-5	HOSE ASSY

AS4050

PARTS	
1	HANDLE COVER FOR CUP
2	SPRING
3	HANDLE COVER FOR CUP
4	HANDLE BASE FOR CUP
5	DUST CUP COVER
6	SAFTY VALVE ASSEMBLY
7	SAFTY VALVE BASE
8	WIND INPUT SPONGE ASSY
9	DUSTBIN
10	SWITCH FOR CUP BOTTOM
11	SEAL RING
12	SEAL RING FOR CUP BOTTOM
13	CUP BUTTOM
14	SWITCH FOR CUP BOTTOM
15	AIR CHANNEL FOR DUSTBIN
16	SEAL RING FOR AIR CHANNEL
17	MESHES FILTERS
18	SEAL RING FOR MESHES
19	SEAL RING FOR MESHES AIR CHANNEL
20	SEAL RING OFR MESHES FILTERS BOTTOM
21	MESHES FILTERS BOTTOM
22	COVER FOR MESHES FILTERS BOTTOM

AS4050